

A Flooring Contractors Operating Guide: Diverting Flooring Offcuts with ResiLoop

Your Role

Divert your flooring offcuts to recycling -

Brief floor layers, consolidate collections at your depot, book free pickups via the ResiLoop App.

Set-up (free)

- Your depot is registered as a ResiLoop Collection Point (free).
- ResiLoop supplies HO/HE/LVT bags and a ResiLoop bin to your depot.

Quality Requirements

- In-scope HO vinyl sheet, HE vinyl sheet and LVT must be bagged separately
- No uplifted/demolition material
- No packaging, sweepings, rubbish
- No adhesives/adhesive tubs/silicone/sealants/metal blades



*Further detail on
what we can and
can't collect*

Your Checklist

- Arrange for the correct bags to be available on site (e.g., with product/accessories deliveries or via installers)
- Brief your floor layers on project specifics:
 - confirmed brand/range/product in-scope
 - areas/levels to collect from (if mixed scope)
 - correct bag use: HO vs HE vs LVT and follow the bag labels Do's and Don'ts
 - returning bags to your depot (not left at the project site unless pre-arranged with ResiLoop and project contractor)
- Ensure filled bags are collated into the ResiLoop bin at your depot (check for contamination)
- Book free pickup via the ResiLoop App when the bin is full and ready for transport
- Optional: If project reporting is required by your client, log/track the offcuts collected using the ResiLoop App so material can be attributed to the project

Need help? Contact us through the App or call 1300 800 568

ONE SCHEME. ONE BIN. MANY BRANDS.